







## MULTIPLE MEMBER ENGINEERED WOOD BEAMS

### CONNECTION DETAILS

The TrussLOK Engineered Wood Fastener has been designed specifically for use in joining multiple-ply engineered wood beams (LVL, LSL & PSL). Using a standard corded or cordless 1/2" low speed/high torque drill, install screws into the side of the outermost ply. As the thread fully engages the final ply, allow the underside of the washer head to pull the plies firmly together. Do not attempt to countersink the fasteners as this may damage the beam. Refer to the information in this bulletin for proper fastener size selection and fastening pattern.



### FASTENER SIZE SELECTION




### FASTENER IDENTIFICATION

For easier selection and post-installation inspection, all TrussLOK fasteners carry an identifying head marking.

TrussLOK 3 3/8" .. F3.3  
 TrussLOK 5" .. . . . F5.0  
 TrussLOK 6 3/4" .. F6.7

### MINIMUM SPACING REQUIREMENTS



- A. Minimum end distance = 3 3/4"
- B. Minimum edge distance = 1 3/4"
- C. Minimum spacing between fasteners in a row = 3 1/2"
- D. Minimum spacing between rows of fasteners = 5/8"

### GENERAL GUIDELINES

- Beams wider than 7" require special consideration by the design professional. The values on the next page do not apply.
- Excessively warped or curved LVL should never be forced into alignment by use of clamps, screws or bolts as splitting may occur, potentially decreasing the carrying capacity of the beam.
- To avoid damaging the beam, fastener heads must not be countersunk. However, if the TrussLOK head needs to be brought flush, prepare the outermost ply with a countersink before installing. Using a 1/2" spade bit, drill a 1/4" deep well into the LVL in the desired fastening pattern, then install the TrussLOK flush.
- Not designed for use with dimensional lumber. Use FastenMaster's TrussLOK-Z fastener for multiple member dimensional wood beams.
- A qualified designer or engineer should always be consulted for critical assemblies and fastening requirements.



**Effective November 1, 2014.** Please reference our website to ensure that you are using the most up to date version.

153 BOWLES ROAD, AGAWAM, MA 01001

413-789-0252


800-518-3569

WWW.FASTENMASTER.COM


**FASTENING PATTERN**

**Top Loaded Beams**

Where all floor joists sit on the beam, fasteners should be spaced two every 24" on center in a staggered pattern as shown.



For beam depths of 18" or more, this pattern should be increased to three fasteners every 24" on center.




**Side Loaded Beams**

Where floor joists are joined to the side of the beam (typically using a joist hanger), this load chart must be used to establish the proper pattern based on the design load as determined by the engineer and noted on the plans.

- Allowable loads are derived from tested fastener values as reported in Derivation of Canadian Design Properties for HeadLOK®, LedgerLOK®, TimberLOK®, TrussLOK® and TrussLOK-Z® Screws, dated November 30, 2009 by Wood Science and Technology Centre, University of New Brunswick.
- A specific gravity of 0.5 was used for all engineered wood (EW) calculations.
- The uniform loads in this table relate only to the capacity of the fastener to transfer shear loads between plies. The capacity of the EW beam may be less and should be checked against the manufacturer's literature.
- Values listed reflect 100% stress level ( $K_p=1.0$ ). The designer may apply adjustment factors to increase or decrease these loads per CSA086-09.
- To minimize rotation, 7" wide beams shall be side loaded only when loads are applied to both sides of the beam with the lesser loaded side bearing at least 25% of the overall design load.

**Assembly Type**



TRUSSLOK	SCREWS	SPACING	MAX FACTORED UNIFORM LOAD APPLIED TO ONE SIDE (PLF)					
			A	B	C	D	E	F
3 3/8"	2	24"	864					
	2	16	1296					
	2	12	1728					
	3	24	1296					
	3	16	1944					
	3	12	2592					
5"	2	24"		675		675		
	2	16		1012		1012		
	2	12		1350		1350		
	3	24		1012		1012		
	3	16		1522		1522		
	3	12		2025		2025		
6 3/4"	2	24"			600		849	600
	2	16			900		1273	900
	2	12			1200		1698	1200
	3	24			900		1273	900
	3	16			1350		1910	1350
	3	12			2025		2547	2025